



### Installing TDM Certificates

---

To access the TDM Administration page and to pull reports from an SSL-encrypted TDM server, two certificates must be installed. Obtain the certificates from your supervisor and follow the instructions below:

#### Trilithic Client

Place certificate file on the Windows desktop and double-click the file icon. Run the configuration wizard. Click the **Next** button until reaching the password prompt. Your supervisor will provide you with the password; enter the password in the **Password** field. Continue to click the **Next** button until the configuration wizard is completed. Allow the configuration wizard to install the certificate in the default location.

#### Trilithic Root

Place certificate file on the Windows desktop and double-click the file icon. In the window that appears next, click the **Install Certificate** button to open the certificate installation wizard. Click the **Next** button. On the Certificate Store page of the wizard, select the **Place all certificates in the following store** option then click the **Browse** button. In the window that appears next, select the **Trusted Root Certification Authorities** option and then click the **OK** button. Continue to click the **Next** button until the configuration wizard is completed.

For Additional Help Contact  
Trilithic Applications Engineering  
1-800-344-2412 or 317-895-3600  
[support@trilithic.com](mailto:support@trilithic.com) or  
[www.trilithic.com](http://www.trilithic.com)

Installing TDM Certificates  
P/N 0010275066 – Rev 07/10  
1 of 1